
BREEZE BANNER STAND

INSTRUCTIONS




⟨1800mm Size⟩
Width 400~700mm
Length 1800mm

⟨1600mm Size⟩
Width 400~700mm
Length 1600mm


*Please use with distinction between top & bottom FRP
*Please use top FRP to adjust height



① Please slot pole into the hole of body same as picture.



② ⟨For 1600mm⟩ Please fit top & bottom rods without connector



③ ⟨For 1800mm⟩ Please fit top & bottom rods with connector



④ Please attach eyelet of banner to rod ends

CAUTION	1. Have to fill base with water to add stability for outdoor use(18L)
	2. Please have to use standard graphic size
	3. Remove while severs storm